

Heimnetz » Kabelmodem » Verbindung

Auf dieser Seite werden Informationen zum Status der Netzwerkkonnektivität des Kabelmodems im Kabelnetz angezeigt.

Gebündelte Downstreamkanäle

Kanal	Frequenz (Hz)	Signalstärke	SNR	Modulation	Kanal ID
1	602000000	66	36	256qam	25
2	170000000	66	37	256qam	5
3	178000000	67	36	256qam	6
4	186000000	66	36	256qam	7
5	194000000	66	37	256qam	8
6	202000000	65	36	256qam	9
7	210000000	66	35	256qam	10
8	218000000	65	36	256qam	11
9	226000000	65	35	256qam	12
10	234000000	67	36	256qam	13
11	242000000	65	36	256qam	14
12	250000000	67	37	256qam	15
13	258000000	66	36	256qam	16
14	266000000	68	38	256qam	17
15	274000000	66	37	256qam	18
16	282000000	67	37	256qam	19
17	290000000	67	37	256qam	20
18	298000000	66	37	256qam	21
19	306000000	67	38	256qam	22
20	314000000	67	37	256qam	23
21	322000000	68	38	256qam	24
22	162000000	66	36	256qam	4
23	618000000	65	37	256qam	26
24	626000000	65	36	256qam	27

Gebündelte Upstreamkanäle

Kanal	Frequenz (Hz)	Signalstärke	Modulation	Symbolrate	Kanal ID
1	36200000	103	64qam	5.120	8
2	58600000	103	64qam	5.120	5
3	45800000	103	64qam	5.120	7
4	52200000	103	64qam	5.120	6

Signale

Kanal ID	Fehlerfreie Codewörter	Korrigierbar insgesamt	Nicht korrigierbar insgesamt
25	14317120	194	485
5	12139433	1048	0
6	12147830	39	0
7	12146958	0	0
8	12147976	5	0
9	12149321	16	0
10	12151381	0	0
11	12143552	0	0
12	12144568	1	0
13	12153758	0	0
14	12142186	0	0
15	12156157	0	0
16	12157179	0	0
17	12158203	0	0
18	12150340	0	0
19	12159558	0	0
20	12160582	0	0
21	12144323	0	0
22	12162963	5	0
23	12152398	0	0
24	12164334	0	0
4	12164203	1485	0
26	12161596	7	0
27	12166693	1	0

