



## Status

[Telefonie Status](#)[LAN Status](#)[DOCSIS Status](#)[Diagnose](#)[Neustart](#)[Über](#)[Ereignisprotokoll](#)

## DOCSIS Status

Verschaffen Sie sich einen Überblick über alle DOCSIS-Parameter Ihres Routers.

### Downstream-Kanäle

Kanal ID	Kanaltyp	Frequenz (MHz)	Modulation	Empf. Signalstärke (dBmV/dBµV)	SNR/MER (dB)	Lock Status
33	OFDM	151~324	1024QAM	4.8/64.8	42	JA
1	SC-QAM	114	256QAM	7.2/67.2	39	JA
2	SC-QAM	130	256QAM	6.6/66.6	40.4	JA
3	SC-QAM	138	256QAM	5.5/65.5	39	JA
4	SC-QAM	146	256QAM	5/65	40.4	JA
5	SC-QAM	602	256QAM	6.2/66.2	39	JA
6	SC-QAM	618	256QAM	6/66	38.6	JA
7	SC-QAM	626	256QAM	6.3/66.3	39	JA
8	SC-QAM	642	256QAM	3.9/63.9	39	JA
9	SC-QAM	650	256QAM	3.1/63.1	37.6	JA
10	SC-QAM	658	256QAM	2.4/62.4	37.6	JA
11	SC-QAM	666	256QAM	1.8/61.8	37.6	JA
12	SC-QAM	674	256QAM	1.6/61.6	37.6	JA
13	SC-QAM	682	256QAM	2.5/62.5	38.6	JA
14	SC-QAM	690	256QAM	4.1/64.1	38.6	JA

14	SC-QAM	690	256QAM	4.1/64.1	38.6	JA
15	SC-QAM	698	64QAM	-0.3/59.7	35	JA
16	SC-QAM	706	64QAM	-0.5/59.5	34.4	JA
17	SC-QAM	714	64QAM	0.1/60.1	34.9	JA
18	SC-QAM	722	64QAM	0.5/60.5	35	JA
19	SC-QAM	730	64QAM	1.3/61.3	35.5	JA
20	SC-QAM	738	64QAM	1.7/61.7	35.7	JA
21	SC-QAM	746	64QAM	1.9/61.9	35.7	JA
22	SC-QAM	754	64QAM	1.5/61.5	35.5	JA
23	SC-QAM	762	64QAM	1.6/61.6	35.7	JA
24	SC-QAM	770	64QAM	1.5/61.5	35.7	JA
25	SC-QAM	778	64QAM	1.9/61.9	35.7	JA
26	SC-QAM	786	64QAM	1.8/61.8	35.7	JA
27	SC-QAM	794	64QAM	2/62	35.5	JA
28	SC-QAM	802	64QAM	1.7/61.7	35.7	JA
29	SC-QAM	810	64QAM	1.8/61.8	36.3	JA
30	SC-QAM	818	64QAM	0.8/60.8	35.5	JA
31	SC-QAM	826	64QAM	1.5/61.5	36.3	JA
32	SC-QAM	834	64QAM	2/62	36.3	JA

## Upstream-Kanäle

32	SC-QAM	834	64QAM	2/82	38.3	JA
----	--------	-----	-------	------	------	----

## Upstream-Kanäle

Kanal ID	Kanaltyp	Frequenz (MHz)	Modulation	Send. Signalstärke (dBmV/dBµV)	Ranging Status
10	OFDMA	29.8~84.8	16_QAM	40/100	Erfolgreich
8	SC-QAM	31	QPSK	43/103	Erfolgreich
5	SC-QAM	51	32QAM	43/103	Erfolgreich
7	SC-QAM	37	QPSK	43/103	Fehler
6	SC-QAM	45	QPSK	43/103	Erfolgreich